

APPLICATION DETAILS

3D ULTRA LURE TAPE + UV

- Degrease the object
 - Detach the tape from the carrier
 - Press slightly in the middle of the position
 - Swipe to the sides under pressure
 - Warm up the object with a hair dryer, toaster etc. and rub it in + brush any wrinkles to the edge.
- Heating the tape is important, this fixes the stretched surface and fixes the heat-activated coating in its position.

Observe the minimum temperature of the object of 20 degrees during processing. Higher temperatures improve the initial adhesion and enable wrinkle-free application.